


## 1 INSTALLATION

See Section 10 for more dimensions



## 2 WIRING

See Section 10 for the Wiring Diagram

TERMINAL	DEFINITION	NOTES
A & B	Actuator (+/-)	#16 AWG (1.3mm sq) or larger wire
C & D	Magnetic Speed Pickup (D is ground)	Wires must be twisted and/or shielded for their entire length Gap between speed sensor and gear teeth should not be smaller than 0.02 in. (.51mm) Speed sensor voltage should be at least 1V AC RMS during crank
E & F	Battery Power (-/+)	#16 AWG (1.3mm sq) or larger wire A 15 amp fuse must be installed in the positive battery lead to protect against reverse voltage Battery positive (+) input is Terminal F
G	Ground Signal	
H & G		Add Jumper for Droop Increase
J	Variable Speed Input	0 - 5V DC
K & L	Droop Select	Active When Closed
M & L	Idle Select	
N	Accessory Input	Load Sharing / Synchronizing,
P	Accessory Power Supply	+10 Volt

### RECOMMENDATIONS

- Shielded cable should be used for all external connections to the ESD control.
- One end of each shield, including the speed sensor shield, should be grounded to a single point on the ESD case.

## 3 ADJUSTMENTS BEFORE ENGINE STARTUP

Make sure the following adjustments are set before starting the engine.

GAIN	Middle Position
STABILITY	Middle Position
SPEED TRIM CONTROL	Middle Position


## 4 START THE ENGINE

The speed control unit governed speed setting is factory set at approximately engine idle speed. (1000 Hz., Speed sensor signal or 600 RPM)

Crank the engine with DC power applied to the governor system. The actuator will energize to the maximum fuel position until the engine starts. The governor system should control the engine at a low idle speed. If the engine is unstable after starting, refer to Section 6 ADJUSTING FOR STABILITY.


## 5 GOVERNOR SPEED SETTING

The governed speed set point is increased by clockwise rotation of the SPEED adjustment control. Remote speed adjustment can be obtained with an optional 5K Speed Trim Control.



## 6 ADJUSTING FOR STABILITY

Once the engine is running at operating speed and at no load, the following governor performance adjustments can be made to increase engine stability.




PARAMETER		PROCEDURE
<b>STABILITY ADJUSTMENT</b>		
A.	GAIN	<ol style="list-style-type: none"> <li>Rotate the GAIN adjustment clockwise until instability develops.</li> <li>Then, gradually move the adjustment counterclockwise until stability returns.</li> <li>Finally, move the adjustment one division further counterclockwise to insure stable performance (270° potentiometer).</li> <li>If instability persists, adjust the next parameter.</li> </ol>
B.	STABILITY	<ol style="list-style-type: none"> <li>Follow the same adjustment procedure, steps 1 - 3, as the GAIN parameter.</li> </ol>
<b>NOTE</b> Normally, adjustments made at no load achieve satisfactory performance. If further performance improvements are required, refer to Section (8) SYSTEM TROUBLESHOOTING.		

## 7 ADDITIONAL FEATURES & OPTIONAL WIRING

### Idle Speed Setting


After the governor speed setting had been adjusted, place the optional external selector switch in the IDLE position. The idle speed set point is increased by the clockwise rotation of the IDLE adjustment control. When the engine is at idle speed, the speed control unit applies droop to the governor system to insure stable operation.



<b>Speed Droop Operation</b>	Droop is typically used for the paralleling of engine driven generators. When in droop operation, the engine speed will decrease as engine load increases. The percentage of droop is based on the actuator current change from no engine load to full load.
1.	Place the optional external selector switch in the DROOP position. DROOP is increased by clockwise rotation of the DROOP adjustment control.
2.	After the droop level has been adjusted, the rated engine speed setting may need to be reset. Check the engines speed and adjust that speed setting accordingly.
<b>NOTE</b>	Though a wide range of droop is available with the internal control, droop level requirements of 10% are unusual. If droop levels experienced are higher or lower than those required, contact GAC for assistance.

<b>Accessory Input</b>	The AUXiliary Terminal N accepts input signals from load sharing units, auto synchronizers, and other governor system accessories. GAC accessories are directly connected to this terminal.
<b>NOTES</b>	Terminal N is sensitive. Accessory connections must be shielded. When an accessory is connected to Terminal N, the speed will decrease and the speed adjustment must be reset. When operating in the upper end of the control unit frequency range, a jumper wire or frequency trim control may be required between Terminals N and J. This increases the frequency range of the speed control to over 7000 Hz (4200 RPM). If the auto synchronizer is used alone, not in conjunction with a load sharing module, a 3M ohm resistor should be connected between Terminals N and P. This is required to match the voltage levels between the speed control unit and the synchronizer.
<b>Accessory Supply</b>	The +10 volt regulated supply, Terminal P, can be utilized to provide power to GAC governor system accessories. Up to 20 mA of current can be drawn from this supply. Ground reference is Terminal G.
<b>CAUTION</b>	A short circuit on this terminal can damage the speed control unit.
<b>Internal Speed Switch</b>	The following procedure will set the overspeed function to approximately 10% above the requested speed.

1.	When the engine is running at the desired speed, push and hold the TEST button.
2.	While holding the TEST button, rotate the OVERSPEED adjustment counterclockwise until the LED lights and the relay reenergizes.
3.	Release the TEST button.
<b>NOTE</b>	Current to the actuator will be removed and the engine will shut off.
4.	After engine stops, press the RESET button or remove the battery power.
5.	Restart the engine. It will return to the original speed setting.
<b>NOTE</b>	Always use the relay contacts provided to shut down the system by a means other than the governor or actuator. It is recommended that the overspeed protection system be tested and verified during scheduled service of equipment.



<b>Wide Range Remote Variable Speed Operation</b>	A single remote speed adjustment potentiometer can be used to adjust the engine speed continuously over a specific speed range.
	Select the desired speed range and corresponding potentiometer value. (Refer to TABLE 1 below) If the exact range cannot be found, select the next higher range potentiometer.
<b>NOTE</b>	An additional fixed resistor may be placed across the potentiometer to obtain the exact desired range. Connect the speed range potentiometer as shown in Section 10 Wiring Diagram & Dimensions
	To maintain engine stability at the minimum speed setting, a small amount of droop can be added using the DROOP adjustment. At the maximum speed setting the governor performance will be near isochronous, regardless of the droop adjustment setting.
<b>NOTE</b>	Contact GAC for assistance if difficulty is experienced in obtaining the desired variable speed governing performance.

TABLE 1

SPEED RANGE		POTENTIOMETER VALUE
900 Hz	540 RPM	1 K
2400 Hz	1440 RPM	5 K
3000 Hz	1800 RPM	10 K
3500 Hz	2100 RPM	25 K
3700 Hz	2220 RPM	50 K
<b>NOTE</b> RPM values shown are for 100 teeth flywheel		

## 8 SYSTEM TROUBLESHOOTING

### Insufficient Magnetic Speed Signal

A strong magnetic speed sensor signal will eliminate the possibility of missed or extra pulses. The speed control unit will govern well with 0.5 volts RMS speed sensor signal. A speed sensor signal of 3 volts RMS or greater at governed speed is recommended. Measurement of the signal is made at Terminals C and D.

The amplitude of the speed sensor signal can be raised by reducing the gap between the speed sensor tip and the engine ring gear. The gap should not be any smaller than 0.020 in (0.45 mm). When the engine is stopped, back the speed sensor out by 3/4 turn after touching the ring gear tooth to achieve a satisfactory air gap.

### System Inoperative

If the engine governing system does not function, the fault may be determined by performing the voltage tests described in Steps 1 through 4. Positive (+) and negative (-) refer to meter polarity. Should normal values be indicated during troubleshooting steps, and then the fault may be with the actuator or the wiring to the actuator. Tests are performed with battery power on and the engine off, except where noted. See actuator publication for testing procedure on the actuator.

STEP	WIRES	NORMAL READING	PROBABLE CAUSE OF ABNORMAL READING
1	F(+) & E(-)	Battery Supply Voltage (12 or 24 VDC)	<ol style="list-style-type: none"> <li>DC battery power not connected. Check for blown fuse.</li> <li>Low battery voltage</li> <li>Wiring error</li> </ol>
2	C(+) & D(-)	1.0 VAC RMS min. while cranking	<ol style="list-style-type: none"> <li>Gap between speed sensor and gear teeth too great. Check Gap.</li> <li>Improper or defective wiring to the speed sensor. Resistance between D and C should be 160 to 1200 ohms. See specific mag pickup data for resistance.</li> <li>Defective speed sensor.</li> </ol>
3	P(+) & G(-)	10 VDC, Internal Supply	<ol style="list-style-type: none"> <li>Short on Terminal P.</li> <li>Defective speed control unit.</li> </ol>
4	F(+) & A(-)	1.0 - 2.0 VDC while cranking	<ol style="list-style-type: none"> <li>SPEED parameter set too low</li> <li>Short/open in actuator wiring</li> <li>Defective speed control</li> <li>Defective actuator, see Actuator Troubleshooting</li> </ol>

**Instability**

INSTABILITY	SYMPTOM	PROBABLE CAUSE OF ABNORMAL READING
Fast Periodic	The engine seems to jitter with a 3Hz or faster irregularity of speed.	<ol style="list-style-type: none"> <li>1. Readjust the GAIN and STABILITY for optimum control.</li> <li>2. Turn off other electrical equipment that may be causing interference.</li> <li>3. Make sure LEAD switch SW1 is set to "OFF".</li> <li>4. If system is still unstable, set DTC switch SW2 to "OFF".</li> </ol>
Slow Periodic	An irregularity of speed below 3Hz. (Sometimes severe)	<ol style="list-style-type: none"> <li>1. Readjust the GAIN and STABILITY Set DIP switches 1 and 2 to "ON" in the following order: First SW1, Second SW2, and Third SW1 &amp; SW2.</li> <li>2. Check fuel system linkage during engine operation for:                     <ol style="list-style-type: none"> <li>a. binding</li> <li>b. high friction</li> <li>c. poor linkage</li> </ol> </li> <li>3. Adjust the DEAD TIME COMPENSATION by adding a capacitor from posts E2 to E3 (negative on E2). Start with 10 mfd. and increase until instability is eliminated.</li> </ol>
Non-Periodic	Erratic Engine Behavior	<ol style="list-style-type: none"> <li>1. Increasing the GAIN should reduce the instability but not totally correct it. If this is the case, there is most likely a problem with the engine itself. Check for:                     <ol style="list-style-type: none"> <li>a. engine mis-firings</li> <li>b. an erratic fuel system</li> <li>c. load changes on the generator set voltage regulator.</li> </ol> </li> <li>2. If throttle is slightly erratic, but performance is fast, then move switch SW1 to the "OFF" position.</li> </ol>

If unsuccessful in solving instability, contact GAC for assistance. info@governors-america.com or call 413-786-5600

**Unsatisfactory Performance**

SYMPTOM	NORMAL READING	PROBABLE CAUSE OF ABNORMAL READING
Engine Over-speeds	<ol style="list-style-type: none"> <li>1. Do Not Crank. Apply DC power to the governor system.</li> <li>2. Manually hold the engine at the desired running speed. Measure the DC voltage between Terminals A(-) &amp; F(+) on the speed control unit.</li> </ol>	<ol style="list-style-type: none"> <li>1. After the actuator goes to full fuel, disconnect the speed sensor at Terminal C &amp; D. If the actuator is still at full fuel-speed then the speed control unit is defective.</li> <li>1. If the voltage reading is 1.0 to 2.0 VDC:                     <ol style="list-style-type: none"> <li>a. SPEED adjustment is set above desired speed</li> <li>b. Defective speed control unit</li> </ol> </li> <li>2. If voltage reading is above 2.0 VDC then check for:                     <ol style="list-style-type: none"> <li>a. actuator binding</li> <li>b. linkage binding</li> </ol> </li> <li>3. If the voltage reading is below 1.0 VDC:                     <ol style="list-style-type: none"> <li>a. Defective speed control unit</li> </ol> </li> </ol>
Overspeed Shuts Down Engine After Running Speed is Reached		<ol style="list-style-type: none"> <li>1. Speed adjustment set too high.</li> <li>2. OVERSPEED set to close to running speed.</li> <li>3. Actuator or linkage binding.</li> <li>4. Speed control unit defective.</li> </ol>
Overspeed Shuts Down Engine Before Running Speed is Reached	1. Check impedance between Terminals C & D. Should be 160 to 1200 Ohms	<ol style="list-style-type: none"> <li>1. OVERSPEED set too low. Adjust 5-6 turns CW.</li> <li>2. Erroneous speed sensor signal. Check wiring.</li> </ol>

SYMPTOM	NORMAL READING	PROBABLE CAUSE OF ABNORMAL READING
Actuator does not energize fully	<ol style="list-style-type: none"> <li>1. Measure the voltage at the battery while cranking.</li> <li>2. Momentarily connect Terminals A and F. The actuator should move to the full fuel position.</li> </ol>	<ol style="list-style-type: none"> <li>1. Replace the battery if weak or under-sized</li> <li>1. Actuator or battery wiring in error</li> <li>2. Actuator or linkage binding</li> <li>3. Defective actuator</li> <li>4. Fuse opens. Check for short in actuator or harness.</li> </ol>
Engine remains below desired governed speed	<ol style="list-style-type: none"> <li>1. Measure the actuator output, Terminals A &amp; B, while running under governor control.</li> </ol>	<ol style="list-style-type: none"> <li>1. If voltage measurement is within 2 VDC of the battery supply voltage level, then fuel control is restricted from reaching full fuel position, possibly due to mechanical governor, carburetor spring, or linkage interference.</li> <li>2. SPEED parameter set too low</li> </ol>



720 Silver Street, Agawam, MA 01001 USA  
 info@governors-america.com  
 www.governors-america.com

**9 SPECIFICATIONS** CE RoHS

PERFORMANCE	
Isosynchronous Operation	± 0.25% or better
Speed Range / Governor	1 - 7.5 KHz Continuous
Speed Drift with Temperature	±1% Maximum
Idle Adjust CW	Min. 1200 Hz below set speed
Idle Adjust CCW	Min. 4100 Hz below set speed
Droop Range	1 - 5% regulation
Droop Adj. Max. (K-L Jumpered)	875 Hz., ±75 Hz per 1.0 A change
Droop Adj. Min. (K-L Jumpered)	15 Hz., ±6 Hz per 1.0 A change
Speed Trim Range	± 200 Hz
Remote Variable Speed Range	500 - 7.5 KHz
Terminal Sensitivity	J 100 Hz., ±15 Hz/Volt @ 5.0 K Impedance L 735 Hz., ±60 Hz/Volt @ 65 K Impedance N 148 Hz., ±10 Hz/Volt @ 1 Meg Impedance P 10 VDC Supply @ 20 mA Max
INPUT / OUTPUT	
DC Supply	12-24 VDC Battery Systems Transient and Reverse Voltage Protected
Polarity	Negative Ground (Case Isolated)
Power Consumption	50 mA continuous plus actuator current
Actuator Current Range	Max. 10 A @ 77°F (25°C)
Speed Sensor Signal	1.0 - 120 VAC
Speed Switch Relay Contacts	10 Amps (N.O. and N.C.)
RELIABILITY	
Vibration	5G @ 20 - 500 Hz
Testing	100% Functional Testing

ENVIRONMENTAL	
Ambient Temperature	-40° to 85°C (-40 to 180°F)
Relative Humidity	up to 95%
All Surface Finishes	Fungus Proof and Corrosion Resistant
COMPLIANCE / STANDARDS	
Agency	CE and RoHS Requirements
PHYSICAL	
Dimension	See Wiring and Outline Diagram
Weight	1.8 lb. (0.82 kg)
Mounting	Any position, Vertical Preferred

**10 WIRING DIAGRAM & DIMENSIONS**

